The Wastes

To remember The 8 Wastes, you can use the acronym "DOWNTIME."





DEFECTS Efforts caused by rework, scrap, and





OVERPRODUCTION Production that is more than needed or before it is needed.





WAITING Wasted time waiting for the next step in a process.






















EXTRA-PROCESSING More work or higher quality than is required by the customer.